

FILLING GAPS IN YOUR SIDEWALK

ONLY ALLOWABLE FOR GAPS 1" OR LESS



What you need:

- Wire brush
- Broom
- Self-leveling concrete sealant
- Caulk gun
- Backer Rod/Sand
- Spoon
- Safety Glasses
- Gloves
- Earplugs
- Scrub brush
- Vacuum
- Pressure washer/Hose

Step 1: PREPARE YOUR AREA

Begin by clearing the area and cleaning the surface with a pressure washer or hose and a scrub brush to remove any grime or debris stuck in or around the gap.



Step 2: FILL GAPS

Place filler material in gap to minimize amount of sealant required. Acceptable gap filling material includes foam backer rod or sand.



Step 3: SELF-LEVELING CONCRETE SEALANT

Fill the remaining gap with sealant, over-filling the gap.

Smooth the excess over the concrete surface with a wet spoon.

ALLOW THE SEALANT TO DRY FOR 48 HOURS AFTER INSTALLATION.

